



Please refer to the RED ARROW above & look for the first four casting numbers on the accumulator body. They will be RF-F3 or RF-F7.

It does make a difference! You must communicate the correct casting number when ordering or servicing your customer!

Our CD4E's are available either with or without an OEM Electronic Solenoid Pac. Extensive testing at our facility has concluded that over 90% of Solenoid Pacs from vehicles with 60,000 or more miles do not operate to their full capacity and can cause a rebuilt transmission and/or our Valve Body to prematurely fail. A defective Solenoid Pac can also produce multiple fault codes, therefore, we STRONGLY RECOMMEND that any Solenoid Pacs falling within the aforementioned criteria be replaced with an OEM Solenoid Pac!

Please be sure to use the correct part number when ordering.

The part number varies depending upon both the casting number and your solenoid pac requirement!

1-866-2GET-VBX

(1-866-243-8829)

www.valvebodyxpress.com

CD4E (F3) WITH Solenoid Pac - VBX Part # FM064 CD4E (F3) WITHOUT Solenoid Pac - VBX Part # FM065

CD4E (F7) WITH Solenoid Pac - VBX Part # FM068 CD4E (F7) WITHOUT Solenoid Pac - VBX Part # FM067